

Alu-Gard Care Guide

Your Alu-Gard Screens should only ever need to be washed down with a soft bristled brush using warm mains water and a mild detergent. Rinse well with mains water to remove any detergent residue paying particular attention to ensure ALL residue is flushed from the mesh retaining areas of the frame. Only mains water is to be used as recycled, bore or tank water is unacceptable and may lead to detrimental corrosion effects. Care should be taken to avoid water entering the lock components. Strong detergents and abrasive cleaners **MUST NEVER** be used to clean your Alu-Gard Screens as these may scratch or damage the surface finish and increase the likelihood of corrosion.

Periodic lubrication of the main lock and auxiliary lock components should only ever be done using graphite powder. Liquid or aerosol lubricants can cause corrosion and damage the locking mechanism.



Alu-Gard

- Regularly wash down using a soft brush, mild detergent and mains water
- Never use strong detergents or abrasive cleaners
- Only use graphite powder to lubricate and maintain the lock and lock components



© Copyright Aluminium Specialties Group Pty Ltd t/as ALSPEC



www.advantageblinds.com.au

Bundaberg - 07 4153 3322

Hervey Bay - 07 4124 5666

Gladstone - 07 4972 7270

Brisbane - 07 3299 2499

Rockhampton - 0417 643 517

