

Roller Blind Care Guide

- Always raise the blinds if windows and doors are open. A strong breeze could catch and damage the blind.
- Avoid exposure to wind or rain. Rain blown onto the blind might stain the fabric and these spots can be difficult to remove.
- To raise the blinds, stand directly in front of the chain, making sure the chain does not rub against the chain wheel mechanism, you will be able to hear and feel the difference.

CLEANING ROLLER BLINDS

Dust with a soft brush or gently sponge clean with warm soapy water, leaving the blinds down to dry.

Spot clean any marks with a soft damp cloth, making sure the cloth is not too wet to guard against water marks.

Do not spray window cleaner on or near the fabric.



Roller Blind

- Raise the blind when the doors and windows are open to prevent damage
- Exposure to rain can cause staining
- Spot clean with a damp, soft cloth and leave the blind to dry before rolling up again
- Do not spray window cleaner on or near the blinds



www.advantageblinds.com.au

Bundaberg - 07 4153 3322

Hervey Bay - 07 4124 5666

Gladstone - 07 4972 7270

Brisbane - 07 3299 2499

Rockhampton - 0417 643 517