

Screen & Door Care Guide

Anodised Surfaces should be kept clean by prompt removal of all dust, dirt, grime and any foreign matter using clean water and a small amount of mild detergent. Do not use any abrasive type cleaning agent or abrasive cloth (such as steel wool) as this will damage the anodised surface. Thoroughly wash off any residue of detergent with clean water.

Deposited grime absorbs moisture and holds it against powdercoated surfaces damaging the coating. Surfaces should be kept clean by prompt removal of all dust, dirt, grime and any foreign matter using a soft sponge with clean water and a small amount of mild detergent. If small scratches occur, they can be buffed out using a good quality car polish. Care must be taken to ensure the coated surface is not removed.

Mesh needs to be cleaned regularly to prevent dirt and dust building up. Using a dusting attachment on your vacuum cleaner, gently suck up any dirt on the mesh. Vacuum both sides of the screen mesh if possible. It is best to work top to bottom when cleaning a screen. If you notice a specific spot or area that is dirty, you can mix up some soap and water to clean your screen. Use a sponge to gently wash the stained area. Only gently scrub as too much force can easily tear the mesh. Finish by drying the screen with a towel.



Screens & Doors

- Regularly wash down using a soft brush, mild detergent and clean water
- Never use strong detergents or abrasive cleaners
- Mesh can be vacuumed to remove dust build up. Tougher spots can be removed by gently washing the spot with soapy water and a sponge. Dry the area with a towel



www.advantageblinds.com.au

Bundaberg - 07 4153 3322

Hervey Bay - 07 4124 5666

Gladstone - 07 4972 7270

Brisbane - 07 3299 2499

Rockhampton - 0417 643 517