

Veri Shades Care Guide

The surface of Veri Shades fabric and tracks will collect a layer of dust over time. Use a soft brush attachment on a vacuum to remove dust, then spot wash other marks.

Veri Shades fabric can be lightly hand washed and dried and can also be ironed with a cool iron. Leave hangers on, and clipped together, and wash by dunking/soaking. *However* ensure you are capable of removing, handling and returning the blades to the track as a *service call fee will be charged* if you require Advantage Screens & Blinds to rehang the blades. If you would like further instructions on how to wash Veri Shade blades, please contact the office.

Veri Shades tracks can be cleaned with a feather duster, or a slightly damp microfiber cloth to ensure the components are also dust free.

At least twice a year (or more in high risk environments), silicone spray should be used to lubricate all the track gears. Before spraying the tracks, remember to slide your Veri Shades fabric over to one side or cover to avoid overspray.

Do not allow insecticides or any harmful chemicals to come in contact with your blinds.



Veri Shades

- Blades can be lightly hand washed and ironed using a cool iron. Soaking in Napisan is possible however check for colour fastness first
- Leave the hangers on when washing. Shake off water and hang back on the track to dry completely before stacking the blades together
- Twice a year use silicone spray to lubricate the track gears



www.advantageblinds.com.au

Bundaberg - 07 4153 3322

Hervey Bay - 07 4124 5666

Gladstone - 07 4972 7270

Brisbane - 07 3299 2499

Rockhampton - 0417 643 517

